

www.EVILUSIONS.com

170 Traymore Blvd.
Eastlake, OH 44095

Thank you for choosing the **EVILUSIONS** Knee Buckler Air Cannon.

OPERATING INSTRUCTIONS

The Knee Buckler Air Cannon is designed to be mounted to the back of one of your attraction's walls and give a great startling scare. Your new cannon should be set on the ground and not elevated. Elevating the cannon could create a potentially hazardous condition for your customers.

- 1) Place mounting ring against wall, mark attachment hole locations of the wall.
- 2) Drill thru holes at each mark and attach cannon through mounting ring with round head machine screws available at any local hardware store.
- 3) Attach supply line from air compressor with ¼" industrial style quick connect fittings.
- 4) Pull adjustment knob on air regulator and turn clockwise to increase air pressure in tank, and counter clockwise to lower pressure in tank. The higher the pressure, the harder the impact on your customer's legs and the louder the noise produced. **DO NOT EXCEED 100PSI.**
- 5) Plug in solenoid valve to a source of 110vac to activate scare. Valve should not be activated for more than 1 second at a time in momentary bursts. Please use provided trigger and follow accompanying instructions for your trigger to get the best function out of your new **EVILUSIONS** product.

DISCLAIMER! Evilusions LLC is not to be held liable for injuries, death, or property damage caused by the improper use of or inability to use this product, misuse of this product for purposes that it is not intended, or complete lack of common sense.

WARNING! This product is not designed to be used in a wet environment. If used outside, or in a damp environment all precautions should be made to prevent it from getting wet. Permanent damage to the product, persons, or property can occur.

Any questions, comments or problems please feel free to contact us
through e-mail at:
gadget@evilusions.com
Or call us at: 440-655-5796